




Spares for Burner



Spares for Combustion Chamber



Spares for Sludge Dosage Assembly



One Year Wear and Tear Parts Kit - General List

Spares for burner

- Diesel nozzle I
- Diesel nozzle II
- Cover gasket

Spares for Sludge Dosage Pump

- Bonded stator
- Rotor
- Universal joint
- Stuffing box gasket

Spares for Combustion Chamber

- Glass fibre rope (door gasket)
- Sealing compound (glue for door gasket)
- Thermocouple "N"

Spares for Flue Gas Fan

V-belts

The exact content depends on incinerator model, TeamTec Generation (TG) and production year.

One Year Wear and Tear Parts Kit

- Contains spare parts that should be changed during one year operation
- These spare parts should be replaced regularly with normal preventive maintenance

Recommended Onboard Repair Parts Kit

- Contains spare parts to be kept onboard at any given time for unforeseen events
- Most common causes of downtime can be eliminated
- Consumed spare parts should be replaced

Recommended Onboard Repair Parts Kit - General List

Spares for Burner

- Flame scrod
- Blast tube
- Ignition electrodes
- Ignition cables
- Nozzle line
- Sludge burner assembly
- Pressure regulator kit
- Photo resistor
- Solenoid valve
- Spline coupling complete
- Shaft seal kit

Spares for Sludge Dosage assembly

- Repair kit for sludge valve
- Solenoid valve 2-way
- Solenoid valve 3-way
- Seal plate gasket
- Mechanical seal
- Stuffing box gasket
- Thermocouple with pocket

Spares for Combustion Chamber

- Repair substance for refractory
- Flue gas restriction ring bricks

Spares for Flue Gas Fan

- Thermocouple "K"
- Shaft bearings

The exact content depends on incinerator model, TeamTec Generation (TG) and production year.



Teamtec AS
N-4902 Tvedestrand | NORWAY

office@teamtec.no +47 37 19 98 00

