



# One Year Wear and Tear Parts

## General list

<b>SPARES FOR BURNER</b>
Diesel nozzle I
Diesel nozzle II
Cover gasket
<b>SPARES FOR SLUDGE DOSAGE PUMP</b>
Bonded stator
Rotor
Universal joint
Stuffing box gasket
<b>SPARES FOR COMBUSTION CHAMBER</b>
Glass fibre rope (door gasket)
Sealing compound (glue for door gasket)
Thermocouple "N"
<b>SPARES FOR FLUE GAS FAN</b>
V-belts

**The exact content depends on incinerator model, TeamTec Generation (TG) and production year.**